



NOTES :-

1. PILE TO BE CUT OFF BELOW CRACK AREA.
2. PILE TOP TO BE CHIPPED LEVEL AND SQUARE.
3. CLAMP THE PILE WITH STEEL CLAMP EITHER BY WELDING OR BY BOLTS AND NUTS TO COVER THE EFFECTED AREA.
4. PILE HELMET TO BE REPLACED WITH 125mm TIMBER PACKING.
5. DRIVE THE PILE TO SET.
6. ALL DIMENSIONS ARE IN mm.

THIS DRAWING SHALL NOT BE REPRODUCED, COPIED, LOANED OR DISPOSED DIRECTLY OR INDIRECTLY; NOR USED ANY PURPOSE OTHER THAN THAT FOR WHICH IT IS SPECIFICALLY FURNISHED WITHOUT PRIOR WRITTEN CONSENT OF INDUSTRIAL CONCRETE PRODUCTS BERHAD.

PROJECT TITLE :

CUT AND COLLAR METHOD



**INDUSTRIAL CONCRETE PRODUCTS BERHAD**

2ND FLR, WISMA IJM, JLN YONG SHOOK LIN  
 P.O BOX 191,  
 46720 PETALING JAYA,  
 SELANGOR DARUL EHSAN, MALAYSIA.  
 TEL : 603-79558888 (13 LINES)  
 FAX : 603-79581111

CHECKED BY :

SCALE

N.T.S

DATE

10/04/2006

REVISION

APPROVED BY :

DRAWN BY

MN06

FILENAME

MN01

CUTJOINMETHOD

DWG. NO.

ICP/PJO/CCM/001